

Trackporter® Helpful Hints

(Full instructions are included in the Owner's Manual. It is recommended each operator read and understand all the information in the Owner's Manuals before operating.)

- **Keep your Trackporter® plugged in when not in use:** Establishing a location to park and charge the Trackporter® at the end of each workday will ensure a full charge for the next use.
- **Front angled shovel adjustment:** The front angled shovel is likely set to the highest position upon delivery. Adjust the front angled shovel to the lowest setting to maintain ground clearance of the highest obstacle (e.g., thresholds) and minimize obstructions under the tracks.
- **Winch mast adjustment:** The winch mast is likely set to the lowest position upon delivery. Adjust the winch mast to the highest possible setting to maximize lifting height and minimize risk of striking overhead obstacles (e.g., feed and water lines) within the facility.
- **Drive control joystick delay:** The operator must press and hold the joystick for 1-second (this is safety feature) before the Trackporter® begins to move in the desired direction of travel.
- **Ambidextrous winch rocker switch (H24 models):** The winch rocker switch may be stowed to the right or left of the joystick depending on operator preference. Also, the winch rocker switch may be detached for handheld use away from the operator's station.
- **Winch free wheel usage:** The winch free wheel knob allows the rapid unspooling of winch rope by hand with the twist of the red knob located at the end of the winch.
- **Keep the winch rope snug during travel:** Retract the winch rope to a snug position to prevent the pulley block from swinging freely and striking personnel or equipment.
- **Approach the carcass from the spine side:** For ease of loading, when possible, pull the carcass onto the front angled shovel with the feet pointing away from the Trackporter®.
- **Keep the pulling point as low as possible:** Attach the pulley block to the lowest D-ring on the front angled shovel or attach the blue strap to the crate across the alley to maintain the lowest anchor point when pulling a carcass into the aisle.
- **Use the red strap for added anchor stability:** Attach the adjustable red strap between the winch mast handle and solid point opposite the line of pull to keep the firm when lifting heavier loads.
- **Winch hardware maintenance increases rope longevity:** Inspect the aluminum fairlead, hooks, pucks, and pulley block for burs, cracks, or dents which may cause abrasions on the winch rope leading to premature failure.
- **Error messages displayed on the Enable 40 Joystick Controller are explained in the owner's manual.**
- **Cover the Enable 40 Joystick Controller (H24/P24 models) with the black bag or a rubber glove when pressure washing or sanitizing.**
- **Remove the remote-control when pressure washing or sanitizing (H24R models).**
- **Enjoy the ease of use, safety, and stability of your new Trackporter!!!**
- **Call (507) 532-5940 with any questions, concerns, or comments.**

Action Manufacturing Inc.

1105 Lake Road, PO Box 620

Marshall, MN 56258

(507) 532-5940